



GPS QUICK START GUIDE

Don't forget to visit the Coxmate [Youtube channel](#) for more guides, hints and product information (just Google "Coxmate Youtube")

Charge Battery – 2+ Hours

- ✓ Use cable supplied
- ✓ Ensure computer USB port is powered up (computers sleep too)
- ✓ Use Smartphone wall adapter

Power it on

- ✓ Press button on right side firmly for at least 2 seconds (avoids accidental activation in bag)
- ✓ Press middle button to change display
- ✓ Use the touch screen to configure settings as required
- ✓ Have a look through the menu
- ✓ Set the time zone – this helps for time/date stamping files for analysis

Give it a go

- ✓ Try out the different mount options
- ✓ Play around with the settings whilst out on the water
- ✓ If you are wearing a heart rate belt it should be detected automatically

Upload Your Data

- ✓ Included is a 12 month subscription to the Coxmate PC Analysis Software
- ✓ Have a play with the software, ensure you right click to see all the functions available to you
- ✓ Train/Analyse/Improve

Look After Your Unit

- ✓ While it is waterproof no electronic device likes salt water
- ✓ Give it a wipe after every session to clear salt water and moisture
- ✓ Use the case provided to protect your unit when in your bag
- ✓ Please ensure the hatch cover (image below) for the micro USB port is closed at all times when not charging or connected to a PC



Visit the Coxmate Website

- ✓ A comprehensive user manual
- ✓ Customer support
- ✓ Accessories for your unit
- ✓ An opportunity to provide feedback